



ITEM	QTY.	DESCRIPTION
1	1	MOUNTING BASE
2	2	CLAMP SCREW
3	1	BRACKET
4	1	SKEWER
5	1	SKEWER SUPPORT
6	2	CLAMP WASHER

Installation Guide

Works with
1" to 3" wide
top rail

Do not
over-tighten
clamp screws

1. Check contents for missing or damaged parts.
2. Loosen bracket # 3 by loosening skewer lever # 4 so bracket will move freely. Loosen skewer # 4 by pulling out on lever (open) and further loosening the nut at the opposite end by hand.
3. Loosen clamp screws # 2 so that the mounting base # 1 will slide over boat railing keeping the clamp screws # 2 on the inside of the boat.
4. Position mounting base # 1 resting firmly on side rail of boat.
5. Hold mounting base # 1 against the outside of the boat rail with mounting base in a vertical (plumb) position slide bracket # 3 against outside of hull at an angle that conforms to the hull

- angle and gives the most surface contact with the hull, then tighten nut on skewer # 4 firmly by hand then re-clamp or push lever on opposite end shut.
6. With bracket # 3 secured, tighten clamp screws # 2 against inside of boat. **Do not over tighten.**
7. After securing, check to see that mount is in a vertical (plumb) position, if not loosen clamp screws # 2 and bracket # 3 and repeat steps 4 through 6.
8. Once mount is secured, attach trolling motor to the EZ Mount and secure per the manufactures recommendations.